

Galactic Water System Installation Instructions

Note: This installation should be done by someone with plumbing experience. If you are not competent to carry out the below steps properly, it is your responsibility to hire a plumber or handyman who is.

1. Turn the cold water valve off under your kitchen sink.
2. Once the water is turned off, open the cold water faucet and let the pressure out.
3. Using an adjustable wrench, remove the cold water line from the valve outlet.
4. Reconnect the water line (the end which you just removed) to the top of the water filter (the outlet side) by hand tightening it, and then giving it a few turns with the adjustable wrench to tighten the fitting (being careful not to overtighten).
5. Take the supply line (provided by us) and attach one end to the cold water valve and the other end to the bottom of the filtration system (inlet side). As before, first hand-tighten and then give it a few turns with the adjustable wrench to tighten the fitting (being careful not to overtighten).
6. Turn cold water valve back on and carefully check for any leaks using a flashlight.
7. Let the water flush the filter for 5-10 min. The water coming through your faucet will be black at first as the carbon dust clears the filter. It should clear in a few seconds. If the water is cloudy with bubbles at first, flush it longer, till the water is clear.
8. Carefully check again for leaks.